

Wireless Heat Alarms

FHH10W



WHY DOES MY ALARM KEEPS BEEPING 🚨?

ONE BEEP 🚨 PER MINUTE

Low battery warning

Low battery warning will probably start at night when the batteries are at their coldest. As the battery continues to get weaker the beeping will become more frequent until it is doing it at all times of day. The battery is not replaceable so replace the alarm. If the alarm is less than 10 years old, contact the installer or the manufacturer.

TWO RAPID BEEPS 🚨 PER MINUTE

Fault signal

If the alarm is less than 10 years old, contact the installer or the manufacturer.

ONE BEEP 🚨 EVERY 12 SECS

The test button is jammed on

Try to release by operating several times. If problem persists and the alarm is less than 10 years old, contact the installer or the manufacturer.

REPEATING SERIES OF THREE BEEPS 🚨 WITH A 1 SEC PAUSE

Full alarm

Check for a possible source of heat. Check for the smell of fire and check all rooms. If nothing obvious check for what was going on in the house.

HEAT ALARMS SELDOM NUISANCE ALARM!

1. Check for a red flashing light – If the alarm is linked to smoke alarms it may be one of those that has sensed smoke – check any smoke alarms.
2. Check for heat from appliances such as local space heaters, cookers, high powered lighting etc.
3. Deep fat frying with lots of hot vapour. Hot fat gives off a hot vapour that is not from burning oil; just oil vapour. **BE CAUTIOUS WITH THIS, IT COULD BE FROM OVERHEATING OIL WITH AN IMMINENT FLASH-OVER TO FIRE**

REPEATED NUISANCE FULL ALARMS

Repeated and intermittent **Nuisance alarms** with no apparent reason. Heat Alarms almost never nuisance alarm but are often linked to smoke alarms that may have set the system off. Check around all smoke and heat alarms in the building to see which one has a repeating and flashing red LED – this one will be the one that has set the system off.

These often occur due to contamination of connected smoke alarms by household dust etc from building and decorating work or deep cleaning. Dust will make the chamber more sensitive to sudden humidity, pressure and temperature changes.

Try vacuuming connected smoke alarms with a soft brush and wipe with a damp cloth (not very wet).

If the problem persists contact the manufacture or installer.

WHY IS THERE A FLASHING RED LIGHT ON MY ALARM?

Is it a single flash every minute without sound? If so this is normal.

Is it a single flash every 10 seconds? If so it is in 'silence' mode.

Is it a constant flashing light with a full alarm sound? If so, Check for a possible source of heat and smoke around connected smoke alarms. Smouldering fires can be difficult to see at the start - check for the smell of fire and check all rooms. If nothing obvious check for what was going on in the house as above.

WHY IS THERE A CONSTANT RED LIGHT ON MY ALARM?

This is a fault. If the alarm is less than 10 years old, contact the installer or the manufacturer for an immediate replacement.

MY ALARM WILL NOT PAIR OR CONNECT TO OTHER ALARMS

Re-pair (learn) to all radio linked devices. If all attempts fail – contact Fireblitz

MY ALARM IS COMPLETELY DEAD

Does it work when tested?

YES

NO

Is the sounder working when tested?

NO

Contact the installer or manufacturer

Contact the manufacturer for advice

ALWAYS read the **ENTIRE** handbook and keep it in a safe place!
ALWAYS make sure you understand the lights and sounds.